

- 4=5/16 X 1 CARRIAGE HEAD BOLTS-A
- 4=5/16 LOCK NUTS-B
- 2=1/2 X 3 1/4 BOLTS-C
- 2=1/4 X 1 BOLTS-D
- 2= 1/2 LOCK NUTS-E
- 2=1/4 LOCK NUTS-F
- 6= 5/16 USS WASHERS-G
- 2=1/4 USS WASHERS-H



RBG 36

HONDA BIG RED REAR BUMPER.

PLACE A 5/16 USS WASHERS ON THE INSIDE OF THE BRACKET FOR A SHIM.

REMOVE THE PIVOT BOLTS UNDER THE BED (ONE AT A TIME) THEN MOUNT THE BRACKET TO THE FRAME.

