

- 2=1/4 X 3/4 BOLTS-A
- 2=1/4 LOCK NUTS-B
- 6=5/16 CARRIAGE HEAD BOLTS-C
- 6=5/16 USS WASHERS-D
- 6=5/16 LOCK NUTS-E
- 2=1/4 USS WASHERS-F



RBG-37W

REAR BUMPER POLARIS
RANGER 800 4X4 2010

THIS IS A PIC OF THE RIGHT REAR BRACKET SITTING ON THE MACHINE. MOUNT USING 1/4 X 3/4 BOLT 1/4 USS WASHER AND 1/4 LOCK NUT. ALSO USE A 5/16 CARRIAGE HEAD BOLT WITH 5/16 USS WASHERS AND 5/16 LOCK NUT. (SECOND PIC.)

THIS IS A PIC OF THE RIGHT REAR BRACKET SITTING ON THE MACHINE. PLACE THE BRACKET ON THE INSIDE OF THE FRAME TAB. USE 5/16 CARRIAGE HEAD BOLT LOCK NUT AND WASHER.

THIS IS A PIC OF THE RIGHT REAR BRACKET SITTING ON THE MACHINE. PLACE THE MAIN BUMPER ON TO THE BRACKETS WITH THE ALUM. SHIELD UNDER THE BUMPER. USE FOUR OF THE 5/16 CARRIAGE HEAD BOLTS WITH FOUR OF THE 5/16 USS WASHERS AND FOUR LOCK NUTS TO SECURE TO THE BRACKETS.

