


4=5/16 X 1 BOLTS
4=5/16 LOCK NUTS
8=5/16 USS WASHERS
4=(8694K73)14" LONG 1" WIDE



ADHESIVE FOAM TAPE
4=SMALL L SHAPED BRACKETS →
MAKE SURE YOU HAVE TWO
LEFTS AND TWO RIGHTS.



CT107

YAMAHA RHINO ALUM. CAB TOP
(SHORTER VERSION)

MOUNT THE SMALL MOUNTING BRACKETS TO THE FRONT OF THE ROLL BAR. THE BRACKETS WILL USE THE STOCK BOLTS IN THE ROUND HOLES OF THE BRACKETS. THEIR IS A RIGHT AND LEFT FOR THE FRONT.



MOUNT THE SMALL MOUNTING BRACKETS TO THE REAR OF THE ROLL BAR. THE BRACKETS WILL USE THE STOCK BOLTS IN THE ROUND HOLES OF THE BRACKETS. THEIR IS A RIGHT AND LEFT FOR THE REAR MOUNTS ALSO.



THEIR WILL BE FOUR 14" SINGLE SIDED ADHESIVE TAPE SUPPLIED. THIS IS TO BE PLACED ONTO THE TOP AND SIDE OF THE ROLL BAR. THE TWO SHORT BENT SIDES OF THE CAB TOP WILL SIT ONTO THESE PIECES OF TAPES.

