


4=5/16 X 1 BOLTS
4=5/16 LOCK NUTS
8=5/16 USS WASHERS
4=(8694K73)14" LONG 1" WIDE
ADHESIVE FOAM TAPE
4=SMALL L SHAPED BRACKETS
MAKE SURE YOU HAVE TWO
LEFTS AND TWO RIGHTS.



CT108

YAMAHA RHINO ALUM. CAB TOP
(SHORTER VERSION)

MOUNT THE SMALL MOUNTING BRACKETS TO THE FRONT OF THE ROLL BAR. THE BRACKETS WILL USE THE STOCK BOLTS IN THE ROUND HOLES OF THE BRACKETS. THERE IS A RIGHT AND LEFT FOR THE FRONT.



MOUNT THE SMALL MOUNTING BRACKETS TO THE REAR OF THE ROLL BAR. THE BRACKETS WILL USE THE STOCK BOLTS IN THE ROUND HOLES OF THE BRACKETS. THERE IS A RIGHT AND LEFT FOR THE REAR MOUNTS ALSO.



THEY WILL BE FOUR 14" SINGLE SIDED ADHESIVE TAPE SUPPLIED. THIS IS TO BE PLACED ONTO THE TOP AND SIDE OF THE ROLL BAR. THE TWO SHORT BENT SIDES OF THE CAB TOP WILL SIT ONTO THESE PIECES OF TAPES.

