




- 4=5/16 X 1 BOLTS
  - 4=5/16 LOCK NUTS
  - 8=5/16 USS WASHERS
  - 4=(8694K73)16" LONG 1" WIDE ADHESIVE FOAM TAPE
  - 2=SMALL L SHAPED BRACKETS
- MAKE SURE YOU HAVE A LEFT AND A RIGHT.



# # CT112

KAWASAKI TERYX ALUM. CAB TOP

THEIR WILL BE FOUR 14" SINGLE SIDED ADHESIVE TAPE SUPPLIED. THIS IS TO BE PLACED ONTO THE TOP AND SIDE OF THE ROLL BAR. THE TWO SHORT BENT SIDES OF THE CAB TOP WILL SIT ONTO THESE PIECES OF TAPES.



**FOR THE FRONT MOUNT THE SMALL MOUNTING BRACKETS TO THE FRONT OF THE ROLL BAR. THE BRACKETS WILL USE THE STOCK BOLTS IN THE ROUND HOLES OF THE BRACKETS. THEIR IS A RIGHT AND LEFT BRACKET FOR THE FRONT.**



**FOR THE REAR MOUNT THE TOP TO THE ROLL CAGE THROUGHT THE CLIPS THAT ARE WELDED ON THE REAR SUPPORT BAR OF THE ROLL CAGE.. USE TWO 5/16 X 1 BOLTS TWO 5/16 USS WASHERS AND TWO LOCK NUTS.**