



- 2 = 3/8 x 2 1/2 Bolt
- 5 = 3/8 SAE Flat Washers (Small)
- 2 = 3/8 Lock Nuts
- 4 = 5/16 SAE Flat Washers (Small)
- 2 = 5/16 Lock Nuts
- 2 = 5/16 x 1 Bolts

-
- 1 = Plate With Three Holes in it (B)
 - 1 = 3/16x 1 x 1 1/2 With 2 Holes (C)

1254 Trailer Hitch Honda Recon

This hitch bolts up to the rear of a Recon 250. One of the 3/8 bolt, bolts up to the rear axle housing and the 2nd bolt, bolts up to the gear box for the rear axle. The bolt (A), comes on the bike . It is by the oil plug.

