

8=1/2 USS WASHERS
1=1/2 LOCK NUT
1=1/2 X 4 BOLT



RH107

KUBOTA RTV 900

PLACE THE RH107 ON TOP OF THE STOCK RECEIVER MOUNT AND BOLT TO THROUGH THE 1/2 HOLE.



PLACE THREE 1/2" WASHERS ON INSIDE OF EACH SIDE OF THE HITCH PLATES TO USE AS SPACERS.



PLACE ONE 1/2" WASHER ON THE OUTSIDE OF EACH SIDE PLATES.

