

- 6 = 1/4 X 1/2 U-BOLTS
- 12 = 1/4 SMALL (SAE) WASHERS
- 12 = 1/4 LOCK NUTS



YOU MUST REMOVE THE PLASTIC BOOT PROTECTORS TO INSTALL THE NEW SS122 METAL PROTECTORS!!!!

SS122

- HONDA 500 4X4
- HONDA 450 4X4
- HONDA 400 4X4
- HONDA 350 4X4

THE SS122 WILL BOLT UNDER THE A ARMS AS SHOWN HERE..

THIS END WILL FACE THE INSIDE OF THE RIM ONCE MOUNTED.

