

6=1/4 GALV. SPACERS 3/8 LONG -A  
6=6MM X 1 X 25MM BOLTS-B

REMOVE PLASTIC GUARDS FOR  
INSTALLING THE NEW METAL  
GUARDS. MUST REUSE THE  
WASHERS ON THE ORIGINAL  
STOCK BOLTS.



# # SS182H

FRONT GUARDS KAWASAKI TERYX 750

