

- 12 = 1/4 Lock Nuts
12 = 1/4 Small Flat Washes (SAE)
2 = 1/4 x 3/8 U-Bolts (B)
4 = 1/4 x 1/2 U-Bolts (A)

- 1 = Pair of SS113 (Right and a Left)

CAUTION

DO NOT OVER TIGHTEN U-BOLTS !
May brake U-bolts or may bend boot protector (Torque no more than 5 foot Lbs). If you bend the boot protector they may rub or tear the CV Boots.
After installing the boot protectors: turn the tires left to right, check the rims and

