

S SAVANT
M MFG., INC.

SS 120

Kawasaki 300, 4x4 (97&up)

CAUTION

DO NOT OVER TIGHTEN U-BOLTS !
May brake U-bolts or may bend boot protector (Torque no more than 5 foot Lbs). If you bend the boot protector they may rub or tear the CV Boots. After installing the boot protectors: turn the tires left to right, check the rims and CV boots for any type of rubbing.

Hardware:

4=1/4x3/4 U Bolt
2=1/4x3/8 U Bolt
12=1/4 Lock Washers
12=1/4 Nuts
12=1/4 Sae Flat Washer

