

- 4=5/16X1 1/2 BOLTS-A
- 6=5/16 USS LARGE WASHERS-B
- 2=1/4X3/8 U-BOLTS-C
- 4=1/4 USS LARGE WASHERS-D
- 4=1/4 LOCK NUTS-E
- 6=8MMX1.25X30 BOLTS-F
- 4=5/16 X 1 1/4" BOLTS ←

THESE BOLTS WILL BE USED FOR A SUBSTITUTE FOR THE 5/16 X 1 1/2" BOLTS ONLY IF THE 3000LB WARN IS USED.

IF THE HAWSE FAIRLEAD FROM WARN IS USED IN PLACE OF THE ROLLER FAIRLEAD USE THE BOLTS AND NUTS THAT OR ON THE HAWS.



IF THE 3000LB WARN WINCH IS USED FLIP THE PLATE OVER AND MOUNT THE WINCH ON TOP USING THE 5/16 X 1 1/4" BOLTS...

IF THE WARN RT25 WINCH IS USED PLACE THE 3/8" THICK ROLLER PLATE ON TOP OF THE MAIN PLATE AND MOUNT.

THE SIMPLEST WAY TO MOUNT THE 298041-R61 IS TO REMOVE THE ALUMINUM SKID PAN. THEN REPLACE THE PAN ONCE THE BRACKET IS MOUNTED.

F WILL BE USED ONLY IF THE WARN RT25 IS UDED.



THIS PLATE IS DESIGNED TO FIT THE RAMSEY 2500LB, AND ALSO THE WARN 2000LB , 2500LB WINCHES.

RAMSEY'S WINCH IS SUPPLIED WITH A ROLLER FAIRLEAD. THE WARN WILL COME WITH A HAWSE FAIRLEAD. THIS DEPENDS ON THE WINCH THAT IS PURCHASED. BOTH THE ROLLER OR HAUS FAIRLEAD WILL MOUNT IN THAT SPECIFIC POSITION.

298041-R61

HONDA RINCON 650 4X4

